ΝΔΟΗΙ

SMALL TYPE POWER AMPLIFIER SERIES WITH MULTI-FUNCTION FOR ELECTRO-HYDRAULIC PROPORTIONAL VALVE DRIVE

Small Type Multi-function Power Amplifier

		6668	ē ē 🛛
	 		PONER
	THE	800000	
12/21 07 45/07 07 3typl" 9 9		69899	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Features

This compact, multi-function power amplifier uses advanced hybrid integrated circuits (HIC).


- Compact design Less than half the size of previous models
- High reliability Circuit board configuration eliminates the need for wiring.
- Multi-function · Simultaneous driving of two valves
 - · Controller with built-in amplifier (EDC-PC6-AWZ-D2-20)
 - · Dither frequency selection function (From Designs 11, 20)

Specifications


Model No.	EDA-PD1-NWZ-D2-11	EDC-PC6-AWZ-D2-20
Function	Amp Type	Amp/Controller Type
Input type	1 DC inputs	Contacts, 6 inputs, DC 2 inputs
Maximum Output Current	900mA (20Ω solenoid)	900mA (20Ω solenoid)
Input voltage	-10 to +10VDC	0 to +10VDC
Input Impedance	50kΩ	50kΩ
Externally Set Variable Resistance	10kΩ	10kΩ
Drive Solenoid	SOL a, SOL b	SOL 1, SOL 2
Zero Adjust (NULL)	0 to 900mA	0 to 900mA
Gain Adjust (GAIN)	0 to <u>900mA</u> 2.5V	0 to <u>900mA</u> 2.5V
External power supply	+5VDC(5mA) -5VDC(5mA)	+5VDC(10mA)
Time Lag (LAG)	0 to 2sec	0 to 2sec
Dither Frequency (DITHER)	80 to 250Hz	80 to 250Hz
Power Supply Voltage	DC24V (DC24 to 30V)	DC24V (DC24 to 30V)
Power Consumption	30VA	60VA
Allowable Ambient Temperature	0 to 50°C	0 to 50°C
Temperature Drift	0.2mA/°C max.	0.2mA/°C max.
Weight	0.3kg	0.4kg
Driven Valve	Pressure, flow, direction control valves	Pressure, flow, direction control valves

Handling

When selecting a location, avoid areas subject to high temperatures and high humidity, and select an area where there is little vibration and dust. 2 Use shielded wire for the analog signal and valve output signal wires. See page I-33 for general precautions 3 The brightness of the LED changes in accordance with the size of the output current.



Installation Dimension Drawings 4 to \$\$4.5 EDA-PD1-NWZ-D2-11 No. Name Name No. 1 Input signal terminal IN1 7 DC24V 2 Input signal terminal COM 8 + 3 Output terminal to valve 9 4 External power supply P5 10 SOL b 110 102 89 5 Input signal terminal COM 11 Output terminal to valve **Ø** 6 External power supply N5 12 SOL a DFFSET 🗭 🗭 🧭 50 72



- Current is supplied to SOL a when input signal voltage polarity is positive, and to SOL b when negative. Either SOL a or SOL b can be driven at any one time.
- Push-pull drive is also supported.
- To measure current, measure the voltage at SOL a terminal 11 and SOL b terminal 9, using terminal 5 as reference. The voltage across the 0.5 Ω current detection resistor at 1A is 0.5V. Use a measurement device with an input impedance of at least 1M Ω .
- To use SOL a only, connect terminal 1 of the knob to amp terminal 2, use an input voltage range of 0 to 5V. (ER, ES only)

Application Examples


1 Adjusting Push-pull Drive for a Special Proportional Valve (Special Specification Direction Control Valve)

a)Overlap Type Proportional Valve

ESD-G01-C5¹⁰-6333D:300mA (Center Current)

ESD-G01-C5¹⁰-6586C:200mA (Center Current)

b)Zero-Lap Type Proportional Valve



As shown in the figure to the left, push-pull control aims at increasing response at the zero point by simultaneously energizing both solenoids.

Adjustment Procedure

- 1)NULL, GAIN, OFFSET Rotate all seven knobs counterclockwise as far as they will go.
- 2)Without any connection between terminals ① and ②, use the OFFSET knob to simultaneously energize SOL a and SOL b as follows.
 - [SOL a 300mA(200mA)
 - [SOL b 300mA(200mA)
- 3)Next, apply +5V to terminal ① (connecting ① and ④), and set the SOL a

GAIN knob to the following. { SOL a 850mA SOL b 300mA

For the SOL b current here, SOL b GAIN should be fully rotated counterclockwise, and its setting should not be changed.

- 4)Apply –5V to terminal ① (connecting ① and ⑥), and set the SOL b GAIN knob for the following.
 - SOLa 0mA SOLb 850mA

This completes the setting procedure.

- The three LAG and NULL knobs should be left rotated fully counterclockwise. There is no need to change their settings.
- EDA-PD1-NWZ-D2-11 is configured with a feedback system, so it does not have a feedback gain adjustment function. In this case, use EDA-PD1-NWZ-D2-11 in combination with the EA-PD4-D10-*-10 NACHI servo amp.

